

Specification Sheet



Description: Flammable Cabinet - 160L

Product Code: 04-1066

Flammable Cabinet - 160L

Product Features

A good mid-ranger in the Chemshed line-up. Taller double door design that holds up to 8 x 20L containers safely and securely.

- Built to comply with the design requirements of AS1940:2017
- Lockable, non-sparking 3 point latching
- Sequential self-closing door system
- Double walled 1.2mm zinc steel construction
- Fitted with ventilation ducts and built in flame arrestors
- Includes Class 3 hazard labelling and other decals required by the standard
- 150mm liquid tight sump
- Sturdy galvanized base shelf that can be removed for easy cleaning
- Adjustable shelf slots – comes with one shelf as standard (additional shelves available)



chemshed

External Dimensions (w,d,h)	Internal Dimensions (w,d,h)	Capacity	No. of Shelves	Weight
1,100 x 450 x 1,220mm	1,018 x 370 x 973mm	160L	1 (plus base)	78kgs

**To request a quote or need further information, contact us now!
Call 0800 951 010 or email customerservicenz@dksh.com**