

Specification Sheet



Description: Flammable Cabinet - 350L

Product Code: 04-1069

Flammable Cabinet - 350L

Product Features

The 350L is the largest model and is designed to hold more of the larger square containers, providing easy visibility and even easier access.

- Built to comply with the design requirements of AS1940:2017
- Lockable, non-sparking 3 point latching
- Sequential self-closing door system
- Double walled 1.2mm zinc steel construction
- Fitted with ventilation ducts and built in flame arrestors
- Includes Class 3 hazard labelling and other decals required by the standard
- 150mm liquid tight sump
- Sturdy galvanized base shelf that can be removed for easy cleaning
- Adjustable shelf slots – comes with two shelves as standard (additional shelves available)
- Strong, continuous piano hinge design



Note: although the capacity is 350L, the legislation states that no more than 250L may be stored in any one cabinet. The reason for the capacity of this cabinet is to allow for larger number of 20L containers to be stored together

chemshed

External Dimensions (w,d,h)	Internal Dimensions (w,d,h)	Capacity	No. of Shelves	Weight
1,160 x 804 x 1,880mm	1,084 x 726 x 1,608mm	350L	2 (plus base)	195kgs

**To request a quote or need further information, contact us now!
Call 0800 951 010 or email customerservicenz@dksh.com**