

Specification Sheet



Description: Corrosive Cabinet - 250L

Product Code: 04-1074

Corrosive Cabinet - 250L

Product Features

The most common model for storing larger amounts of corrosive liquids, the versatility of this unit will hold multiple sizes of Class 8 corrosive liquids with ease. Solid and dependable.

- Built to comply with the requirements of AS3780
- Lockable, non-sparking 3 point latching
- Self-closing door system
- Double walled 1.2mm zinc steel construction
- Fitted with ventilation ducts and built in flame arrestors
- Includes Class 8 hazard labelling and other decals required by the standard
- 150mm liquid tight sump
- Sturdy galvanized base shelf that can be removed for easy cleaning
- Adjustable shelf slots - comes with two shelves as standard (additional shelves available).



chemshed

External Dimensions (w,d,h)	Internal Dimensions (w,d,h)	Capacity	No. of Shelves	Weight
1,100 x 500 x 1,750mm	1,018 x 420 x 1,503mm	250L	2 (plus base)	131kgs

To request a quote or need further information, contact us now!
Call 0800 951 010 or email customerservicenz@dksh.com